


Usage of VuUtil.exe (Windows Application)

Vu+ util is a software to write flash memory in the VuPlus STB.


Before running the Vu+ util software, please connect PC with VuPlus STB by a serial cable.

And make sure that VuPlus STB is connected to local network by ethernet cable.


1. Execute Vu+ Util



2. Select Com port (Com1~10)




3. Click Connect Button



Now you can see the message, "Serial port open success. Please turn on your box".

If you see the message "Serial port open failure", then check first if there is another program using the same port.

4. After turning on your box, you can see next screen.



If you want to disconnect com port, click Disconnect button.


Local IP : IP address of PC

Remote IP: IP address of Vuplus STB

Set up the IP address accordingly, and press Set IP Button

If you want to set up Remote IP address using DHCP, check DHCP option first before clicking Set IP Button

4. If IP address setup has been successful, you can see next screen.



5. Next click the open button, then you can see the dialog window

Select a image file(*.nfi) at the dialog window

Button x will remove the file that you have selected

Vu+ Util

Com port :

COM1

Disconnect

Local IP :

192 . 168 . 102 . 41

☐ DHCP

Remote IP :

192 . 168 . 102 . 45

Set IP

IP Setup Success,

0/0

NFI File

C:\http\20091209\wvuplus_new.nfi

x

Open

Flash

Exit